

**VORSICHT!**

Nicht springen

**ATTENTION!**

Do not jump




**POZOR!**

Neskákat








**POZOR! UWAGA!**




Neskákat'

Nie skakać




**4x**


A		Ø10x40mm	10
B		Ø8x30mm	32
C		Ø3,5x30mm	40
D		Ø3,5x14mm	16
E		3,5x30mm	06
F		7,0x50mm	20
G		7,0x80mm	08

H		12
I		08
J		01


01





02




03









04




05




06




07



08







09








10


4x



11



12



**VORSICHT!**

Nicht springen

**ATTENTION!**

Do not jump

**POZOR!**

Neskákat

**POZOR!**

Neskákat'

**UWAGA!**

Nie skakać